








150 Beam Wall Mounting Instruction




Important

Using appropriate fasteners to suit the mounting surface is the responsibility of the installer.
Units should be suspended at two points at all times to avoid the over-loading of fasteners.


<p>2000 Max. Span</p>  <p>Within 0.5m Join or bend</p>	<p>Top View</p>  <p>Timber</p>	<p>Top View</p>  <p>Gyprock</p>	<p>Top View</p>  <p>Metal plug</p>	<p>Top View</p>  <p>Plastic plug</p>	 <p>Ø 5 Slot</p> <p>Ø 20 Power Entry</p> <p>131.5</p> <p>50</p> <p>13</p>
--	---	--	---	---	---

150 Beam Anti-Vandal Wall Mounting Instruction




Important

Using appropriate fasteners to suit the mounting surface is the responsibility of the installer.
Units should be suspended at two points at all times to avoid the over-loading of fasteners.








10559-02-C

150 Beam concealed fixed end plate Wall Mounting Instruction




Important


Using appropriate fasteners to suit the mounting surface is the responsibility of the installer.
Units should be suspended at two points at all times to avoid the over-loading of fasteners.

<p>2000 Max. Span</p> <p>Within 0.5m Join or bend</p>	<p>Top View</p>  <p>Timber</p>	<p>Top View</p>  <p>Gyprock</p>	<p>Top View</p>  <p>Metal plug</p>	<p>Top View</p>  <p>Plastic plug</p>	
---	---	--	---	---	--

10559-08-A




Suspension




- Units should be suspended at two points at all times for safety and to avoid overloading suspensions.
- A maximum loading of 50kg is recommended on a single wire at any one time.
- Units should always have a suspension point within 0.5m of a joint or bend.
- Proper installation of units to avoid damage and injury, is the responsibility of the installer.

Physical Connection



After pins are slid into place, fasten the wing nut and screw as shown. Make sure positive pressure is applied, to tightly bring together the joining units

Electrical Connection



Connect same coloured wires via wire connectors provided. Ensure wires are pushed in tight and check they are secure.