





LEDPOD 40SQ Installation Instructions

Patent pending


1 Ensure pre-drilled holes are deburred and excess swarf is removed.




2 Rotate retaining clasps in as shown.



3 Apply pressure as shown to deform clasp into place in a circular motion.




4 Fit clasp into place until the clamping ends are equally centred over the hole. Use tool to centre clasp until equally pressure can be felt and inspect by eye.




5 Feed wires through tube. Be careful not to sever wires whilst feed past pre-installed retaining clasps.

Pull a loop of wire through as shown.



6 Install Scotchlok connectors to the 18-16 AWG (0.75-1.5) red and black wires. Connect the corresponding colour wires of the Driver to the Scotchloks and assure the clamp is secured. Max wire insulation 3.5mm OD




7 CAREFULLY feed the Scotchloks to the left of the clasp and the driver to the right with the driver connector hanging out.

Proceed to connect the LEDPOD


LEDPOD Removal Steps

1 Insert removal tool into the 2mm holes in the LEDPOD

With firm pressure, rotate the LEDPod 90° to release the luminaire from the clasp.






2 Carefully peel back the IP silicone seal one side at a time.




Be sure to re-attach the silicone seal ready for reinsertion.

3 Carefully remove the LEDPOD from the clasp, ensuring not to damage or disconnect wires in the process.



Light direction







The notch indicates the direction of the light, Asymmetrical LEDPods




8 Push LEDPOD in until it snaps into place and the outer surface is flush with the outer surface of the tube.

Prod the rim of the clear silicone IP Seal to provide a tighter fit.

LEDPod Soft Start Relay Installation Instructions (Use for 350mA drivers only)



IMPORTANT : Connect to 24V DC supply input, to the Blue and Red Soft starter wires. DO NOT connect power to any other wires. Refer to printed label on Soft Starter.



Soft starter complete with pre-fitted connectors

Move components down to make room for retaining clasp insertion. Refer to drawings 10655-01 & 10655-02 for LEDPod installation